



# Security Case with Kickstand and Anti-Theft Cable


for iPad 10.2" 7th Generation, iPad Air3, iPad Pro 10.5

PAD-SCKTW10

## Contents:


- Case Main body (Plastic Case & Silicon Cover)
- Cable Lock with (2) keys
- Manual

### Tablet insertion step-by-step




1. Remove the silicon cover of the plastic case.
2. Pull the stopper of the plastic case.
3. Slide the tablet into the case from bottom side.
4. Push the stopper back to fix the tablet.
5. Install the plastic base into silicon cover.

### Tablet Removal step-by-step




1. Remove the silicon cover.
2. Release the stopper.
3. Take the tablet out from upper side.
4. Push the stopper back.
5. Install the plastic base into silicon case.

### Tablet Locking



1. Use key push and turn it to unlock position.
2. Tie the cable to fixed object.
3. Insert the tip of lock into the case lock slot.
4. Turn the key to let the lock at lock position.

### Tablet Unlocking



1. Use the key to move lock to unlock position.
2. Release the lock.