



Oxivir® Tb

Ready to Use Surface Cleaner & Intermediate Disinfectant, General Virucide, Tuberculocide

A ready-to-use disinfectant cleaner based on proprietary hydrogen peroxide (AHP®) technology to deliver fast, effective cleaning performance.

Features/Benefits

- Bactericidal, Tuberculocidal and Virucidal in one minute; Fungicidal in three minutes
- Meets Health Canada's standard for cleaning and decontaminating blood and body fluids
- Compatible with most hard, non-porous surfaces while harnessing the power of Accelerated Hydrogen Peroxide® (AHP) technology
- AHP® active breaks down into water and oxygen after use
- Delivers fast and effective cleaning performance while being non-irritating to eyes and skin

Applications

- Clean and disinfect high-touch surfaces





Oxivir® Tb

Ready to Use Surface Cleaner & Intermediate Disinfectant, General Virucide, Tuberculocide

Oxivir® Tb Ready to Use Surface Cleaner & Intermediate Level Disinfectant, General Virucide, Bactericide, Tuberculocide is a ready-to-use disinfectant cleaner based on proprietary hydrogen peroxide (AHP®) technology to deliver fast, effective cleaning performance. Oxivir® Tb Wipes is a one-step cleaner disinfectant wipe.

Use Directions

- Pre-clean heavily soiled areas.
- Apply solution by cloth or disposable wipe to hard, non-porous environmental surfaces.
- All surfaces must remain wet for one-minute to kill bacteria, HIV-1, HBV and HCV.
- Air Dry, wipe surfaces to dry and remove any residue, or rinse with potable water as necessary.
- Provides broad spectrum sanitizing of non-food contact surfaces in just 30 seconds.
- Not recommended for use on brass, copper, aluminum, bronze, granite, zinc or marble.
- Food contact surfaces require rinsing with potable water after disinfection.

Technical data	Oxivir® Tb
DIN Reg. No.	02283522
Color	Colorless liquid
pH	2.5–3.5
Scent	Natural cherry almond (no fragrance added)
Shelf Life	2 Years

Product	Pack size	Dilution	Product code	
Oxivir® Tb	12 x 32 fl. oz. / 946 mL Flip Top Bottles Plus Two Trigger Sprayers	Ready-to-use	4277293	🇨🇦
Oxivir® Tb	1 x 330 gal. Tote Container	Ready-to-use	5871690	🇨🇦
Oxivir® Tb	1 x 55 gal. Drum Container	Ready-to-use	101104053	🇨🇦
Oxivir® Tb	1 x 5 gal. Drum Container	Ready-to-use	101104054	🇨🇦

Safe handling

Please make sure your employees read and understand the product label and Safety Data Sheet before using this product. The label contains directions for use; and both the label and SDS contain hazard warnings, precautionary statements and first aid procedures. SDS are available online at www.diversey.com or by calling 888.352.2249. Improper use or dilution may result in damage to surfaces and may result in health and physical hazards that match those of the concentrate.

Accelerated Hydrogen Peroxide® and Design are trademarks of Diversey, Inc.